



	BATTERY "A" CHARGE RATE AMMETER
2	BATTERY "B" CHARGE RATE AMMETER
3	AUDIBLE WARNING DEVICE
4	"TEST MANUAL START" ILLUMINATED P.B.
5	"SYSTEM A HEALTHY" INDICATING LAMP
6	"AC SUPPLY ON" INDICATING LAMP
7	"SYSTEM B HEALTHY" INDICATING LAMP
8	AUTO START ON/OFF SWITCH
9	"ON DEMAND" INDICATING LAMP
10	"RUNNING" INDICATING LAMP
11	"LOW OIL PRESSURE" INDICATING LAMP
12	"HIGH WATER TEMPERATURE" INDICATING LAMP
13	"LOW WATER TEMPERATURE" INDICATING LAMP
14	"FAILED TO START" INDICATING LAMP
15	"AUTO START INHIBITED" INDICATING LAMP
16	"EMEGENCY START" PUSHBUTTON
17	"SHUTDOWN" PUSHBUTTON
18	AC ISOLATOR CRANKING FROM BATTERY "A" INDICATING LAMP
19	CRANKING FROM BATTERY "B" INDICATING LAMP
20	

1st ISSUE	JB		11-03-04
REVISION	DRAWN BY	CHECKED BY	DATE
<b>NORTH WEST SWITCHGEAR Ltd</b>			
MORECAMBE		LANCASHIRE	
EN12845 CONTROLLER G.A. FOR USE WITH LPS 1239 APPROVED ENGINES			
A3- 17009			